



working range

37-142' main boom + 33-56' lattice extension

7



Dimensions are for largest Grove furnished hookblock and headache ball, with anti-two block activated.

TMS900E

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

GROVE